



TACLOCKTM **USER** **MANUAL**

// TACLOCK

FEATURES

All Mechanical

No batteries, no electronics, built for total reliability. and ready anytime.

Tamper Proof Lock Clutch

Clutch disengages under force to block break-ins and prevent tampering.

Key Override

Backup key access for fast emergency entry or if you forget your combination.

Improved Ergonomics

Larger dials, smoother motion, faster code input.

1500+ Combo Options

Over 1,500 unique codes for advanced protection.

Proprietary Design

Built exclusively for TruckVault systems and drawers.

Noise Dampening

Precision fit with rubber strip on strike plate reduces rattle during vehicle movement.

1 Year Warranty

Backed by a full 1-year performance guarantee.

// COMBINATION

Factory Combination : 1 - 5 - 4 - 8

**Record your new combination
and keep it in a safe place.**

* Pick any 4 numbers (no duplicates)

If you lose your combination and all three override keys, contact customer service at 800-967-8107

// TACLOCK

HOW TO OPERATE

1 Combo



Enter in your four digit combination code, (each punch should provide a distinct "click").

2 UnLock




Turn the locking knob into the "OPEN" position and then proceed to open the drawer.

3 Override



If needed, Insert your key into the lock and turn to unlock position. Then turn the locking knob into the "OPEN" position.

4 Lock




Ensure the drawer is fully closed. Turn the locking knob to the "LOCK" position.

// TACLOCK

HOW TO CHANGE THE COMBINATION.

For your safety and to ensure maximum security, it's essential to change the default factory-set combination on your TacLock before regular use. Leaving the default code in place may leave your gear vulnerable to unauthorized access.



1

Open Drawer - Remove the 2x Phillips screws on the back lock, and remove the housing.

Factory Combination:

1 - 5 - 4 - 8




2

Pull out the lock module.

Press both the center tab and the left tab at the same time to release the pins.

3



Remove all Pins.

4




While depressing the center and left tabs on the lock body place your pins in the correct slot for your desired combination.


Combination must be 4 different numbers. They must be sequential based on the ABCD labels. Wherever you place the "A" pin will be the first number in your combination.

Replace all the empty slots with the remaining dummy pins.

5




// HOW TO CHANGE COMBINATION CONT...



6

All the pins must be oriented in the same way so the visible letters are facing downward on the lock module.

Be sure that the word "TOP" on the module is facing the opposite direction of the letters.



7

Press the lock module into the back of the lock body firmly until it seats itself. Replace the back cover.



8

*** BEFORE *** closing the drawer and locking it. Test the lock function using the new code several times.

WARRANTY INFORMATION

TACLOCK™ WARRANTY AND LIABILITY DISCLAIMER

TruckVault Inc. guarantees to the original purchaser that the TacLock locking system is free from defects in material and workmanship for a period of 1 year (12 months) from the date of delivery of the fully installed TruckVault unit.

In the event of a defect in materials or workmanship, TruckVault's sole obligation will be to repair or replace the defective lock component at its discretion. Replacement may be fulfilled with a new or refurbished part that meets original specifications.

Warranty Terms and Conditions:

This warranty applies only to the original purchaser of a TruckVault system equipped with the TacLock.

Claims must be submitted with proof of original purchase, including purchase date and customer contact information.

Advance authorization from TruckVault Customer Service is required prior to initiating any warranty service. Contact: 800-967-8107 or support@truckvault.com.

This warranty does not apply to any lock that has been altered, misused, damaged due to negligence, or used outside of intended operating conditions.

This warranty is void if the product has been serviced by anyone other than authorized TruckVault personnel.

TacLock is not intended for commercial applications outside its use in TruckVault drawer systems unless approved in writing by TruckVault Inc.

Legal Disclaimer:

To the fullest extent permitted by law, all implied warranties—including but not limited to merchantability, fitness for a particular purpose, and warranties arising from course of dealing or trade—are disclaimed. In no event shall TruckVault Inc. be liable for any incidental, consequential, or punitive damages arising from the use or inability to use the TacLock, including but not limited to loss of access due to a forgotten combination or accidental lockout.

Some states do not allow the exclusion or limitation of incidental or consequential damages or the duration of implied warranties, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary by state.



800. 967 . 8107 (Toll Free)

360 . 855. 0464 (Local)

truckvault@truckvault.com

www.truckvault.com

TruckVault Inc.
315 Township Street
Sedro-Woolley, WA
98284
